

# **MOREFUN MF919Security Policy**

Date: 2022.07.21

**Document Version: 0.2** 



# **Contents**

1. Doc	ument Information	3
1.1.	Evolution Follow-up	3
1.2.	Acronyms & Terms	3
1.3.	References	3
1.4.	Targeted Readers	4
2. Int	roduction	5
3. Ge	eneral Description	6
3.1.	Product Overview	6
3.2.	Product Inspection	6
3.3.	Product Identification	6
4. Gu	ıidance	8
4.1.	Installation	8
4.2.	Periodic Inspection	8
4.3.	PIN Confidentiality	10
4.4.	Self-Test	10
4.5.	Decommissioning/Removal	11
4.6.	Management Security	11
5. Pr	oduct Hardware Security	12
5.1.	Temperature Humidity and Power	12
6. Pr	oduct Firmware Security	13
6.1.	Software Development Guidance	13
6.2.	Communication Method and Protocols	
6.3.	SRED Security	14
6.4.	Vulnerability Detection and Follow-up Action	14
6.5.	Firmware Update	15
7. Ke	y Management	17
7.1.	Cryptographic Algorithms	17
7.2.	Key Table	17
7.3.	Key Loading Policy	19
7.4.	Key Replacement	20
8. Sy	stem Administration	21
8.1.	Configuration Settings	21
8.2.	Default Value Update	
		20



# 1. Document Information

# 1.1. Evolution Follow-up

Revision	Type of modification	Date
0.1	Document creation	2022-03-25
0.2	Add some comments	2022-07-21

# 1.2. Acronyms & Terms

Abbreviation	Description
N/A	Not Applicable
PED	PIN Entry Device
PIN	Personal Identification Number
RSA	Rivest Shamir Adelman Algorithm
TDEA	Triple Data Encryption Algorithm
SHA	Secure Hash Algorithm
MK/SK	Master Key/Session Key
MSR	Magnetic-stripe Reader
ICCR	Integrated-circuit card reader
SRED	Secure Reading and Exchange of Data
DUKPT	Derived Unique Key Per Transaction
AP	Application Processor
SP	Security Processor

### 1.3. References

- [1] ANS X9.24 1:2017, Retail Financial Services Symmetric Key Management Part 1: Using Symmetric Techniques
- [2] ANS X9.24 Part 2: 2016, Retail Financial Services Symmetric Key Management Part 2: Using Asymmetric Techniques for the Distribution of Symmetric Keys
- [3] X9 TR-31 2018, Interoperable Secure Key Exchange Key Block Specification for Symmetric Algorithms



- [4] ISO 9564-1, Financial services-Personal Identification Number (PIN) management and security —Part 1: Basic principles and requirements for PINs in card-based systems
- [5] ISO 9564-2, Banking-Personal Identification Number management and security Part 2: Approved algorithms for PIN encipherment
- [6] Morefun Security Software Development Lifecycle
- [7] MF919 Bilingual Manual
- [8] OP secure user guidance.docx

### 1.4. Targeted Readers

This guideline is mainly intended for the following personnel:

• Those who deploy the MF919 physical devices at the end-user site.

Execute the deployment of new MF919 devices, for instance:

- > Firmware update
- > Test before terminal deployment
- Administrator or outlet administrator

Execute management and on-site guidance, for example:

- Key modification
- Perform routine tests and terminal maintenance



# 2. Introduction

This Security Policy provides guidance for the proper and secure usage of Payment Card Industry (PCI) Payment Terminal Security (PTS) Approved Point of Interaction version 6.0 devices, such as the MF919 terminal.

The security policy applies to all MF919 terminals, which are PCI PTS version 6.0 POI approved. Any use of the device in an unapproved method will violate the PCI PTS approval of the device.



# 3. General Description

#### 3.1. Product Overview

The MF919, is a handheld Point of Sale (POS)terminal device ,which has an integrated LCD Screen with Touch Screen securities for PIN Entry Device(PED) function. It also has integrated USB, Cellular(GPRS), WiFi, Bluetooth, Printer, ICCR, Contactless card reader and MSR reader. The device is used to process credit and PIN-based debit card transactions under an attended environment. This guideline constitutes the main information source for technicians, intended for the administrator and the site administrator to manage and deploy MF919 devices.

# 3.2. Product Inspection

When the device is received via shipping, carefully inspect the shipping carton and its contents for possible tampering or damage.

- 1. Validate the authenticity of the sender by verifying the shipping tracking number and other information located on the product order paperwork.
- 2. Remove the MF919 unit from the shipping carton.
- 3. Remove any protective plastic wrap and place the unit on a table or countertop.
- 4. Remove the clear protective film from the display.
- 5. Save the shipping carton and packing material for future repacking or moving the device.

### 3.3. Product Identification

To verify if your MF919 product is PCI approved as a PED (PIN Entry Device), locate the PCI Identification number at "Settings->About phone->Model & hardware->Firmware version".

Go to the PCI Security Standards Council web site (www.pcisecuritystandards.org) andve rify that the PCI Hardware Version matches the Hardware number on the list of Approve d PIN Transaction Security (PTS) Devices.





Figure 1:MF919Appearance

The product name and hardware version are printed on the label, which is on the back of device. It is to be noticed that the label should not be torn off, covered or altered.

Item:POS Terminal

Model:MF919

Made-in-China

Input:5.0V === 2.0A

Spec:919N/4G/W/BT

HW:MF\_ADHW\_2.01 FW:MF\_ADFW\_2.01

SN:A9822030480001

Fujian MoreFun Electronic Technology Co.,Ltd.

Figure 2: Device Label

The hardware version approved by PCI PTS 6.0 is: MF\_ADHW\_2.01

The firmware version approved by PCI PTS 6.0 is: MF\_ADFW\_2.01



Figure 3: Version information

Fujian Morefun Electronic Technology Co.,Ltd  $\ _{7}$  /  $_{22}$ 



### 4. Guidance

Before use and deployment, please read [7] first, which introduces the precautions for device safety and use.

#### 4.1. Installation

The terminal must be used in an attended environment.

The terminal should be kept away from the direct sunlight, high temperature, humidity or dusty places. The terminal should also be kept away from the complex environment of electromagnetic radiation to prevent interference or damage to the device.

### 4.2. Periodic Inspection

The merchant or acquirer should check daily that the keypad is firmly in place and ensure that there is no overlay anomaly coverage. Such checks would provide warning of any unauthorized modification to the terminal, and other suspicious behavior of the terminal.

Check daily whether the MSR card slot has an additional card reader or other inserted bugs.



Figure 4: MSR Slot

The merchant or acquirer should also check that the installation/maintenance operations are performed by a trusted person. Especially, check daily if the ICC reader

Fujian Morefun Electronic Technology Co.,Ltd 8 / 22



slot is damaged, such as abrasion, painting or other machining marks, and if there is any suspicious object like lead wires over ICC reader slot, or any unknown object inside IC card slot.



Figure 5: ICC Reader Slot

Check the terminal daily whether it has been tampered. When the terminal tamper is triggered, the device displays a warning that the device is under attack, and without other messages.



Figure 6: Warning under attack

If you find these suspicious circumstances, please stop using the device immediately and notify the security personnel of your company and your local Morefun representative or



service provider to confirm if the device has been tampered. Please send back for repair when tampered.

The terminal does not contain parts which can be repaired by users. Do not attempt to disassemble the terminal to repair.

### 4.3. PIN Confidentiality

The MF919 device is a hand-held mobile device without a Privacy Shield, and it is required to provide cardholders with the necessary privacy during transactions, especially PIN entry:

- Take the terminal to the cardholder to enter the password.
- Cover with body or hand when entering the password to prevent the password from being peeped.



Figure 7: Safe PIN Entry Example

#### 4.4. Self-Test

The MF919 device performs a self-test:

- when a device is powered on
- when the device restarts
- it will restart a self-test automatically at least every 20 hours

The following components are tested during a self-test:

- Key field authenticity and integrity
- Firmware tamper inspection
- Firmware authenticity and integrity inspection

During self-test, there is no display to avoid affecting the normal display.



If the result of self-test is safe, then the self-test completes and no message displays.

If the result is fault, then it prompts "Warning under attack" (see Figure 5) and the device is forbidden from working.

### 4.5. Decommissioning/Removal

When the device is no longer used for permanent decommissioning reason, the administrator of the device needs to gather the device and erase all the key materials on it. This can be done by disassembling the device to make it tampered.

For temporary removal, there is no need to change the state of the device, as all the keys are still protected safely by the main board hardware tamper mechanism.

# 4.6. Management Security

- Perform a policy that requires all maintenance technicians accessing your store to log in and use certificates with their respective photos to verify their respective identity, and any technicians performing any work on PIN keypad and/or terminal will be accompanied by the store clerk during any work period.
- Execute a program, (i.e., check the serial number of the terminal whenever the device starts or is powered on (to ensure the device is not replaced. If the device is replaced, stop using the terminal and notify your Morefun customer relationship manager.
- ➤ Inspect the terminal visually every day to ensure that no foreign object is found in the smart card slot; make sure that no wire leads from the smart card slot.
- Develop a default response plan. This identifies the steps to be taken if a suspected violation occurs and who will execute each step. This plan needs the list of all personnel to isolate your payment system and all those who need to be informed. They include your local law enforcement authority, your acquiring bank, your processor, security assessor and your payment system provider.
- ➤ Keep track of terminals replaced in every store. Whether they are from the store inventory or sent to the store by maintenance technicians.



# 5. Product Hardware Security

In hardware security, physical tamper-proofing mechanism is designed that can prevent sensitive data against the leak and detection when the external environmental conditions and the operating conditions change.

When the device is under external attacks, such as drilling, laser, chemical corrosion, being uncovered etc., an attack detection mechanism will be triggered. All keys will be erased. These mechanisms ensure that sensitive data will not be leaked.

Terminal security shall not be affected by changes in environmental conditions. Its power and temperature range shall be within the range specified in the user manual. Beyond this range, the operating terminal will trigger tamper events and make the terminal stop executing the transaction and the display will show that the terminal has been tampered.

# 5.1. Temperature Humidity and Power

The following are the temperature and humidity specifications of the MF919 device:

- Operating temperature range: 0 °C ~ 40 °C
- Humidity: 10% to 90% range( non-condense)
- Storage temperature range: -20 °C ~ 75 °C
- Storage humidity range: 20% ~ 93% (non-condensing)

Subjecting the MF919 device to an extreme environmental condition will result in a tamper event. Any temperature above 105  $\pm$  15 °C or below -40  $\pm$  10 °C will result in tamper.

Specification of power supply:

- Lithium Battery:7.4V
- Security Processor Voltage: 2.8±0.1V ~ 4.2+0.1V
- DC input: 5.0V

In addition, if the backup button battery voltage is beyond the range of  $2.1\pm0.1$  V $\sim$ 4.2 $\pm0.1$ V, the device will be tampered.



# 6. Product Firmware Security

Only signed firmware can be updated to the device.

The Cryptographic algorithms utilized for signing are listed as below,

RSA 2048, used for signature verification.

SHA 256, used for calculating hash for data integrity.

The regular self-test mechanism ensures that firmware already downloaded into the device cannot be modified.

### 6.1. Software Development Guidance

The developer must respect the following security guidance.

- All payment-based firmware must be subject to formal review and security audit before signing and use.
- The reviewer must be an eligible individual not related to the author of the POI PED code.
- Code review must be managed by an auditable process that displays the review code with the security test already performed, it requires the sign-up of the personnel who executes code review and security test. Testers shall pay attention to any problematic programs occurring during the code review and security test period.
- Such a review must be subjected to such a review whenever the code changes.
- The firmware review must be performed according to the requirements of the PCI
   POI PED and the guideline listed in this document.

Authorized firmware must be signed before being published. The signing must be performed under the condition of dual control and knowledge segmentation.

Morefun provides software-programming guide to developers to develop applications compliant with PCI security requirements. Please refer to [6] when developing SRED applications.

The device does not allow unauthorized or unnecessary functions.

#### 6.2. Communication Method and Protocols

The device supports USB communication. The device supports USB to virtual serial adapter. USB interface for download, de-trigger function, follow the standard USB protocol.



MF919devices supports the following communication methods and protocols.

Protocol Name	Component	Version
IP	AP	Linux(4.14.133)
TLS v1.2	AP	OpenSSL(1.1.0g)
GPRS/WIFI/Bluetooth	AP	AP vendor

### **OP applications development:**

Development must respect [8].

The following points need to take attention.

- 1. The client must authenticate the CA certificate and client certificate.
- 2. The cipher suite of the server which the terminal connects with should be as secure as:
  - TLS\_RSA\_WITH\_AES\_128\_CBC\_SHA or more secure.
- 3. The server which the terminal connects with should be configured to require Client Authentication.
- 4. The server should disable the SSL protocol, and the device does not support SSL. Use TLS v1.2 or higher.

Use of any method not listed in the policy invalidates the device approval.

# 6.3. SRED Security

The account data can be protected by MK/SK DEK (Data-encryption Key, TDES 192bits or AES 128bits) and DUKPT Future Keys (TDES 128bits). The MF919 does not support format-preserving encryption techniques. After transaction or time out or other abort, the plain-text account data must be deleted immediately.

The device always provides SRED functionality and does not support the disablement (turning off) of SRED functionality.

The device firmware of does not support whitelisting for the pass-through of clear-text account data. For more details, please refer to [6].

### 6.4. Vulnerability Detection and Follow-up Action

When new vulnerabilities, threats or bugs are detected via public resource or the customer, Morefun performs analysis to see if the new vulnerabilities, threats or bugs may impact the MF919 security. Morefun contacts a PCI lab for consultation if a delta evaluation is necessary.



- If the vulnerabilities, threats or bugs impact the MF919 security, Morefun immediately informs customers of the vulnerabilities, threats or bugs analysis result via email and sends the patch to the customers.
- If hardware change needs to be involved to fix the issue, customers should return their MF919 devices to MF919 manufacturing facility for the repair. When a new vulnerability occurs, MF919's security team will send a vulnerability notification email to the customers (especially their security managers).
- Bug report contact with Morefun email: support@morefun-et.com

### 6.5. Firmware Update

When a new firmware version is released, Morefun will send an update notification email with the newly released firmware to the customers. The device supports both local and remote method of Firmware update.

- **Local method:** Firmware can be updated by USB upgrade.
  - Copy update firmware to the root directory of a USB disk.
  - ➤ Insert the USB disk to the MF919 device.
  - Enter the **Firmware and application updates** menu with Administrator authorization, and select update.
  - After that, device will reboot automatically and finish upgrade.
- Remote method: Deploying updates to the device as they become available. The
  device's firmware is maintained up to date thanks to the TMS, no user operations
  is needed.

#### The Procedure of update:

- The device receives the signature file.
- ➤ Decrypt the signature by using the corresponding public key, and capture the length and the SHA-256 of code data.
- According to the length, calculate the SHA-256 of code data. If the same, then update the firmware, otherwise discard the firmware and decline to update.

The format of the signature file of the Firmware is below:

256 bytes RSA signature Code data

#### The frequency limited:

Only 4 times per hour, and do not exceed 15 minutes per time.

For example, if you download Firmware at 10:00, then you have only 3 times to update



Firmware, if 4 times exhaust, you cannot update firmware until 11:00.



# 7. Key Management

MF919 supports the following key management methods:

Master/Session Key

This method uses a hierarchy of Master Key and Session Key. The master key is distributed with 2 key components, then injected complying with the principles of dual control and split knowledge. The Session Key is distributed under the protection of Master Key. These keys can be replaced by the same methods whenever compromise is known or suspected.

### DUKPT

This method uses a unique key for each transactions, and prevents the disclosure of any past keys used by the transaction-originating device.

The use of the POI with unapproved key management systems will result in incompliance with PCI PTS POI security requirement.

# 7.1. Cryptographic Algorithms

The device includes the following algorithms:

- 1. RSA(Signature verification, 2048 bits)
- 2. SHA-256
- 3. Triple DES
- 4.AES
- 5. ECC(in support with NIST P-256 and P-521)

### 7.2. Key Table

All keys store in the PED and the detail please refer to the key table.

Key name	Size (Bits)	Algorithm	Purpose/ Usage	Store
MK/SK	192	TDES	Encryption of	Manually entered into the TOE
MK(Master			MK/SK	in 2 plain-text components
Key)	128	AES	PEK,MACEK,DEK	Stored in cipher-text enciphered under the Root Key in flash
MK/SK	192	TDES	PIN encipherment	Injected into the TOE in



PEK(PIN-encry	128	AES	for online PIN	cipher-text
ption Key)				Stored in cipher-text enciphered under the Root Key in flash
MK/SK MACEK(MAC-e	192	TDES	Message authentication	Injected into the TOE in cipher-text
ncryption Key)	128	AES	authentication	Stored in cipher-text enciphered under the Root Key in flash
MK/SK	192	TDES	Encryption of SRED	Injected into the TOE in
DEK(Data-encr yption Key)	128	AES	Data	Stored in cipher-text enciphered under the Root Key in flash
DUKPT IPEK	128	TDEA	Derive DUKPT future keys	Manually entered into the TOE in 2 plain-text components  Delete after generating future keys
DUKPT Future keys	128	TDEA	Encrypt transaction data under DUKPT scheme	Derived from IPEK.  Updated each time KSN is increased  Stored in the SP internal Flash, encrypted by Root Key
SP_SBI_PUK( SP Secure Boot Image Public Key)	2048	RSA	SP Secure Boot Image authentication	SP OTP
SP_PUK( SP Firmware Public Key)	2048	RSA	SP firmware authentication	SP internal flash
APK_RPUK (APK Root Public Key)	2048	RSA	Acquirers APK Public Key authentication	SP internal flash
APK_PUK (APK Public Key)	2048	RSA	Application authentication	AP internal flash



OTA_PUK (OTA Public Key)	2048	RSA	OTA package authentication	AP internal flash
SPL_PUK (SPL Public Key)	2048	RSA	AP SPL authentication	AP OTP
UBOOT_PUK (UBOOT Public Key)	2048	RSA	AP Uboot authentication	AP internal flash
SYS_PUK  (AP Firmware  Public Key)	2048	RSA	AP firmware authentication	AP internal flash
Root Key	192	AES	Encrypt keys	Stored plaintext in the SP CPU internal Battery-backed 512bits Secure Memory

# 7.3. Key Loading Policy

The key-loading techniques supported by the device fall into the following two categories.


- Clear-text key components through the keypad (MK/SK MK (Master Key), DUKPT IPEK),
- Symmetric encrypted keys injection (MK/SK PEK (PIN-encryption Key), MK/SK MACEK (MAC-encryption Key), MK/SK DEK(DATA-encryption Key)).

Manual key loading complie with the principles of dual control and split knowledge.

Input key components from the keypad. Input two key components then XOR result in PINPAD. Before any key component input, you must input the corresponding PSW (password) and pass the password authentication. If input the PSW firstly, the value will be stored for the next authentication.

Please refer to the following figure:





net had 1

When the device leaves the manufacture, all keys field are empty. The firmware cannot export any key value, only supports setup and use key. It will be unsuccessful if any downloaded key is the same to the existed key in the PINPAD.

- ➤ Key injection and management must be performed in a safe manner.
- ➤ Key component password, and other credentials must be managed under dual control and knowledge split to ensure that no one can use two credentials at the same time.
- ➤ Key management security objectives must comply with the PCI PIN transaction security requirements.
- ➤ Use of different key-management system than supported by the TOE will invalidate any PCI approval of this POI.
- ➤ Key exchange must be performed based on knowing all passwords or sensitive information or a suspected compromise.

### 7.4. Key Replacement

Any keys should be replaced with a new key value whenever the compromise of the original key is known or suspected, and whenever the time deemed feasible to determine the key by exhaustive attack elapses.



# 8. System Administration

# 8.1. Configuration Settings

The security functions are an inherent part of firmware functions. No security sensitive configuration settings are necessary to be tuned by the end user in order to meet security requirements.

### 8.2. Default Value Update

The device does not include any certificate for testing purpose after being manufactured.

There are two PSW – PSW1 and PSW2, which must be managed under dual control and split knowledge. PSW1 controls the key component 1 input, PSW2 controls the key component 2 input in the same key field. The default value of both PSW is all zeros, and is enforced to be re-set to a valid PSW before first time use.

PSW modifying is at "Settings->Set PSW". The process must be in turn of Old PSW1> New PSW1>Old PSW2>New PSW2, the PSW will only be checked and modified after finishing the complete process, then the new value will be stored for the next verification. The new PSW cannot be the same to the old PSW and default PSW. There are five times limit for the PSW input, if wrong input is over five times, the device will never access of key injection.



# 9. Roles and Services

The customers of MOREFUN are acquirer or Value Added Resellers (VAR). We also refer to VAR as acquirer directly. MOREFUN sells devices to VAR and provides technique and maintenance support to VAR. VAR sells the devices to end users and provides services to their end user. MOREFUN, VAR and end users play different roles in operating the device.

The table below shows different roles and operations:

	Role	Operation	
VAR	Administrator	1.Change the default control password	
		2.Perform Key Loading	
		3.Perform firmware update	
End user	Operator	Perform transaction	
MOREFUN	Maintainer	1.Sign firmware	
		2.Repair device and unlock the device if tampered	